




Using the control panel



hp LaserJet 9040/9050mfp

Copy

1. Touch COPY.
2. Touch Describe Original.
3. Touch Page Content.
4. Select Text, Photo, or Mixed.
5. Adjust the options for Density, Sharpness, and Background Removal and then touch OK.
6. Press the START button.

E-mail

1. Place the original on the glass or in the ADF.
2. Touch E-MAIL.
3. If requested, type your user name and password.
4. Complete the remaining fields.
5. Select the settings you want to use by touching Settings and then touching OK, or use the default settings.
6. Press the START button.

Fax

1. Place the original on the glass or in the ADF.
2. Touch FAX.
3. Touch Settings and describe the original.
4. Use the keyboard to type the phone number.
5. Press the START button.

Describes the original document. The HP LaserJet 9040/9050mfp automatically detects the original document size (most sizes).

Use this feature to select the pop-up style "what's this?" help or print step-by-step instructions by using "show me how."

Use this feature to adjust the control panel contrast.

Use this feature to send your document in e-mail.

Use this feature to fax your documents to a standard fax machine. Fax settings and speed dials can also be selected here.

Describes the copied output, including finishing options.

Use these controls to adjust the size and the density of the scanned image.

MENU opens the device menus, including "Retrieve Job."

SLEEP


STATUS shows the current supply status.

STOP cancels a current job.

RESET returns the device to configured defaults.

START

More help



or



Q3726-90950